

KINGSPLUM

Architectural Frameless Sliding Shower Screen

we offer professional installation in Sydney city area, please refer to the installation guide if you live in other city of Australia.

Pick up address: U5/10 Blackstone St Wetherill Park NSW 2164


Installation team representative: 0410 519 393



INLINE COMPONENT RANGE

KINGSPLUM KIT

- Polish finish
- Includes 3x hex/allen keys



1x Recessed round handle



2x Door upper rollers



2x Door stabiliser guides



2x Fixed panel rail connectors



2x Door stoppers



1x Floor guide





2x Rail wall brackets

PRE-DRILLED RAIL

- Polish finish
- 30mm H x 10mm W

KPRail 1650


KPRail 1950



WALL BRACKET

- Chrome plated solid brass
- Use to install fixed glass panels to wall

KPHW013



BOSTIK 6S SILICONE

- 300g tube
- Translucent finish
- High performance neutral cure silicone sealant with mould inhibitor


KP6S



SLIMLINE RAIL WALL BRACKET

- Polish finish
- Only required if using a 650mm wide modular fixed glass panel

KPHW014



DOOR BUMPER STOPPER

- 2130mm L - PVC
- Suits 10mm glass

KPstopper01



OPTIONAL EXTRA COMPONENTS

WATER BAR

- Polished aluminium
- 10mm H x 10mm W x 1450mm L
- Silicone to floor in front of door


KPbar1450



WATER SEAL

- 2130mm L - PVC
- 26mm long PVC fin
- Fits to 10mm thick fixed panel


KP2130



OFFSET WALL BRACKET

- Chrome plated solid brass
- Use to install fixed glass panels to wall

KPHW030





TOOLS REQUIRED

- Cordless drill
- \varnothing 8mm masonry drill bit
- Hacksaw
- Screwdriver
- Pencil
- Tape measure
- Level
- Silicone gun


CAUTION!



- 1 Select left or right handing of door panel



- 2 Fit the two fixed panel wall brackets (KPHW013) to the opposite wall to the door opening




KINGSPLUM


Pick up address: U5/10 Blackstone St Wetherill Park NSW 2164

Installation team representative: 0410 519 393 / 02 8090 2558

- 3 Rotate the floor guide to suit left or right handing door opening





- 4 Using the grub screw, attach the floor guide to the bottom leading corner of the fixed panel



- 5 Fit fixed panel to wall brackets


NOTE: Check floor level. If floor is not level, fit glass ensuring it is level to the highest side




- 6 Fit the internal block of the first wall bracket inline with the fixed panel top holes



INSIDE SHOWER



- 7** Fit the internal block of the second wall bracket to opposite wall ensuring it is level with the first block




- 8** Cut both ends of rail to suit width between wall bracket blocks
- NOTE: Cut fixed panel end first ensuring the holes in rail line up with the holes in glass fixed panel



- 9** Slide 2x stoppers and 2x wall bracket sleeves onto rail before fitting to blocks
- NOTE: Select the slimline rail wall bracket on the fixed panel side if using a 650mm W fixed panel




- 10** Attach rail to wall brackets by sliding wall bracket outer sleeves over the wall blocks and secure with grub screws



11

Attach fixed rail connectors to connect rail to fixed glass panel




12

Fit 2x rollers to door facing out


Fit door bumper to leading door edge

Hang door on rail while fitting bottom edge into floor guide and adjust level



13

Fit door stabiliser guides to door and adjust to prevent door from lifting off rail





14

Fit recessed handle to door

15

Silicone fixed panel into place



RETURN COMPONENTS

WALL BRACKET x2

- Chrome plated solid brass
- Use to install fixed glass panels
- to wall

KPHW013



90° GLASS BRACKET x1

- Polish finish SS304
- Required when installing with a
- glass return panel

KPHW031




BOSTIK 6S SILICONE


- 300g tube
 - Translucent finish
 - High performance neutral cure silicone sealant with mould inhibitor
- KP6S



RETURN PANEL MEASURING TIPS



- Return panel width measured from wall to front face of front/ixed inline panel
- If using a wall bracket to afix return panel to wall, a deduction needs to be made to the glass return panel width to allow for bracket gap (commonly 3mm to 5mm)



- When measuring " W " for a coniguration with a return panel, width is measured from wall to inside edge of 10mm thick return panel


TOOLS REQUIRED

- Cordless drill
- \varnothing 8mm masonry drill bit
- Hacksaw
- Screwdriver
- Pencil
- Tape measure
- Level
- Silicone gun

CAUTION!





- 1 Fit return panel wall brackets at the same height as fixed panel wall brackets



2


Fit return panel to wall brackets and pack leading edge to avoid glass on tile

NOTE: Check floor level. If floor is not level, fit glass ensuring it is level to the highest side



3

Fit 90° bracket to return panel



See inline installation steps 1-14

4

Silicone return panel

